


Sådan opdatere du firmwaren på din DI router.

Advarsel! Opdatere aldrig over en trådløs forbindelse.

Når routeren er sat til computeren med et kabel åbner du internet explorer og skriver <http://192.168.0.1> i adresse baren.

Det følgende vindue ville nu komme op.



LOGIN

Log in to the router:

User Name : Admin ▾

Password :

Log In

Skriv admin som brugernavn og der er ikke nogen adgangskode. Tryk på **[Log In]** for og forsætte.

	SETUP	ADVANCED	TOOLS	STATUS	SUPPORT
INTERNET	INTERNET CONNECTION				Helpful Hints... If you are new to networking and have never configured a router before, click on Setup Wizard and the router will guide you through a few simple steps to get your network up and running. If you consider yourself an advanced user and have configured a router before, click Manual Configure to input all the settings manually.
WIRELESS SETTINGS	There are two ways to set up your Internet connection: you can use the Web-based Internet Connection Setup Wizard, or you can manually configure the connection.				
NETWORK SETTINGS	INTERNET CONNECTION WIZARD				
	If you would like to utilize our easy to use Web-based Wizards to assist you in connecting your new D-Link Systems Router to the Internet, as well as configure the Wireless settings, click on the Setup Wizard button below.				
	<input type="button" value="Setup Wizard"/>				

Klik på menuen [Tools], og klik på [Firmware] i venster side af skærmen. Det følgende billede ville du nu se..

	SETUP	ADVANCED	TOOLS	STATUS
ADMIN	FIRMWARE			
TIME	Firmware Upgrade			
SYSLOG	The Firmware Upgrade section can be used to update to the latest firmware code to improve functionality and performance.			
EMAIL SETTINGS	To check for the latest firmware, click the [Check Online Now...] button. If you would like to be notified when new firmware is released, place a checkmark in the box next to Email Notification of Newer Firmware Version.			
SYSTEM	<input type="button" value="Save Settings"/> <input type="button" value="Don't Save Settings"/>			
FIRMWARE	FIRMWARE INFORMATION			
DYNAMIC DNS	Current Firmware Version : Latest Firmware Version :			
SYSTEM CHECK	Current Firmware Date :			
SCHEDULES	<input type="button" value="Check Online Now for Latest Firmware Version"/>			
	FIRMWARE UPGRADE			
	Note: Some firmware upgrades reset the configuration options to the factory defaults. Before performing an upgrade, be sure to save the current configuration from the Tools -> System screen.			
	To upgrade the firmware, your PC must have a wired connection to the router. Enter the name of the firmware upgrade file, and click on the Upload button.			
	Upload : <input type="text"/> <input type="button" value="Browse..."/>			
	<input type="button" value="Upload"/>			
	FIRMWARE UPGRADE NOTIFICATION OPTIONS			
	Automatically Check Online for Latest Firmware Version : <input checked="" type="checkbox"/> Email Notification of Newer Firmware Version : <input type="checkbox"/>			

Klik på knappen [Gemmelse], og find den downloadet firmware fil. Normalt ville firmware filen have en endelse der hedder bin eller bix. Makere firmwaren og klik på [open] og klik derefter på [Apply] for og starte opdateringen.

Advarsel! Du må ikke slukke for enheden mens opdateringen er i gang.